DPTO 22 SNAP PAC R-Series Controllers

SNAP PAC R-Series Controllers

Features

- Rack-mounted industrial controller with I/O processor included.
- Two independent 10/100 Mbps Ethernet network interfaces
- Wired+Wireless models add wireless LAN network interface as well
- One RS-232 port with handshaking, suitable for modem communication using PPP
- MicroSD card slot for removable data storage
- Full-featured control and HMI software included with purchase
- 🔰 UL approved

Description

The affordable and compact SNAP PAC R-series programmable automation controllers provide powerful, realtime control and communication to meet your industrial control, monitoring, and data acquisition needs. Part of the Opto 22 SNAP PAC System[™], the R-series PAC is a rackmounted, industrially hardened unit that can handle multiple tasks involving digital and analog control, serial string handling, communication, and enterprise connectivity.

Used with the included PAC Project Basic software suite (or PAC Project Professional, purchased separately), the Ethernetbased SNAP PAC R-series controller runs control programs written in Opto 22's PAC Control[™] software. It can monitor and control a wide range of devices and equipment wired to the I/O on its own rack and to I/O on distributed racks equipped with SNAP PAC EB-series brains. Alternatively, the R-series controller can be used as a slave to a larger, SNAP PAC S-series standalone industrial controller or a SoftPAC[™] software-based controller for PC-based control.

SNAP PAC R-series controllers are well suited to original equipment manufacturers (OEMs), system integrators, and end-users in process control, discrete manufacturing, or hybrid industries and applications.

Several models are available:

 SNAP-PAC-R1, SNAP-PAC-R1-FM, SNAP-PAC-R1-W, and SNAP-PAC-R1-B each control a mix of SNAP analog, digital (both 4-channel and high-density), and serial modules. Full digital functions include high-speed counting; quadrature counting; and pulse, period, and frequency measurement. The -FM model is Factory Mutual approved. The -W model adds wireless LAN capability (see "Wired+Wireless Communication" on



SNAP-PAC-R1 controller

page 2 for more information). The -B model is designed to mount on SNAP B-series racks so that older I/O units can be easily upgraded to a newer controller.

 SNAP-PAC-R2, SNAP-PAC-R2-FM, and SNAP-PAC-R2-W also control a mix of SNAP analog, 4-channel and highdensity digital, and serial modules. High-speed digital functions are not included. The -FM model is Factory

Part Numbers

Part	Description
SNAP-PAC-R1	Analog/digital/serial rack-mounted con- troller with two Ethernet ports and high- speed digital functions
SNAP-PAC-R1-B	Analog/digital/serial rack-mounted con- troller with two Ethernet ports and high- speed digital functions, for B-series racks
SNAP-PAC-R1-FM	Analog/digital/serial rack-mounted con- troller with two Ethernet ports and high- speed digital functions, Factory Mutual approved
SNAP-PAC-R1-W	Wired+Wireless analog/digital/serial rack- mounted controller with two wired Ether- net ports, one wireless Ethernet interface, and high-speed digital functions
SNAP-PAC-R2	Analog/simple digital/serial rack-mounted controller with two Ethernet ports
SNAP-PAC-R2-FM	Analog/simple digital/serial rack-mounted controller with two Ethernet ports, Factory Mutual approved
SNAP-PAC-R2-W	Wired+Wireless analog/simple digital/ serial rack-mounted controller with two wired Ethernet ports and one wireless Ethernet interface

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3007 • support@opto22.com © 2007–2016 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

PAGE 1

DATA SHEET Form 1594-160505 Mutual approved. The -W model adds wireless LAN capability (see page 2 for more information).

Built-in functions and comparisons of the SNAP-PAC-R1 and SNAP-PAC-R2 are shown in the table on page 10.

Ethernet Communication

All SNAP PAC R-series controllers communicate over standard 10/100 Mbps Ethernet networks and can be attached to an existing network. The controllers can also be used in an independent control network built with standard, off-the-shelf Ethernet hardware.

SNAP PAC R-series controllers include two 10/100 Mbps Ethernet interfaces for networking to Ethernet hosts and to other I/O units. These independent Ethernet ports have separate IP addresses that can be used with PAC Project[™] Professional software to set up redundant network links to safeguard the availability and reliability of an I/O system, or to segment a control system's network from the enterprise LAN.

Supported protocols over Ethernet include EtherNet[™]/IP, Modbus[®]/TCP, SMTP, SNMP, FTP, and OptoMMP.

Wired+Wireless Communication

SNAP-PAC-R1-W and SNAP-PAC-R2-

W controllers add wireless capability to communications. In addition to the two wired network interfaces, these models have a wireless network interface as well, so each PAC has a total of three separate IP addresses—two wired and one wireless. Wired+Wireless PACs can be used wirelessly or on a wired network, or both at once.

For flexibility in designing your wireless network, wireless communication includes support for 802.11a, b, and g standards. Wired+Wireless PACs can be used with a variety of wireless switches and other infrastructure hardware. For the best security, the 802.11i WPA2/AES standard is supported, while older WPA and WEP security standards are included for backwards compatibility.

Because wireless functionality is in the PAC itself, no additional parts are required within the control system for wireless use. All SNAP PAC racks and SNAP I/O modules can be used either wired or wirelessly. You can switch from one network to the other without reconfiguring I/O or changing field wiring.

SNAP PAC R-Series Controllers

Just like a laptop computer with a wireless connection, all functionality remains the same whether the Wired+Wireless PAC is used wirelessly or as part of a wired network. Supported protocols remain the same. And control programs run the same on both networks without reprogramming.

Serial Communication

SNAP PAC R-series controllers provide an RS-232 serial link to support Point-to-Point Protocol (PPP) modem connections—for creating TCP/IP networks over serial or PSTN (Public Switched Telephone Network) lines—as well as remote serial device communication.

The RS-232 serial interface supports either a modem connection using PPP or general-purpose communication with serial devices, allowing you to send and receive data from

a serial device connected directly to the controller. For additional serial interfaces, you can add one or more SNAP serial communication modules on the rack.

NOTE: The R-series controller does not include an RS-485 port and cannot be used to control Opto 22 serial I/O processors, such as the SNAP PAC SB-series brains. Use an S-series controller for serial brains.

I/O Mounting Racks

SNAP PAC R-series controllers must be connected to the appropriate rack to avoid damage to the controller. Both the SNAP-PAC-R1 and R2 are designed to work with SNAP PAC mounting racks, which are available with 4, 8, 12, or 16 positions for Opto 22 SNAP I/O modules. Part numbers are SNAP-PAC-RCK4, SNAP-PAC-RCK8, SNAP-PAC-RCK12, and SNAP-PAC-RCK16. Factory Mutualapproved versions of these racks, with part numbers ending in -FM, are also available.

Ethernet PAC for Legacy I/O Racks

The **SNAP-PAC-R1-B** is a PAC-R1 for use with older SNAP B-series racks. This PAC provides an upgrade path from legacy brains and rack-mounted controllers such as the B3000, SNAP-B3000-ENET, or SNAP-UP1-ADS that use B-series racks. See the SNAP B-series Racks data sheet (form 0784) for more information.

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2007–2016 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

SNAP-PAC-R1-W

ACE

DATA SHEET Form 1594-160505

OPTO 22 SNAP PAC R-Series Controllers

SNAP PAC R-Series Controllers

The SNAP-PAC-R1-B uses the same firmware and has the same functionality as the SNAP-PAC-R1, except that 4-channel digital modules can be placed only in slots 0-7 due to limitations on the rack.

SNAP I/O


The SNAP PAC R-series controllers support all SNAP I/O modules available on our website. SNAP digital I/O modules contain four input or output points, and SNAP high-density digital modules contain 16 or 32 input or output points. SNAP analog modules contain 2 to 32 points, depending on the module.

Software

SNAP PAC controllers use Opto 22's **PAC Project** Microsoft[®] Windows[®]-compatible automation software for programming, human-machine-interface (HMI) development, and OPC connectivity.


Two versions of PAC Project are available:

- **PAC Project Basic** includes PAC Control[™] for developing control programs, PAC Display[™] for creating operator interfaces, and PAC Manager[™] configuration software.
- PAC Project Professional adds expanded versions of PAC Control and PAC Display plus a SoftPAC softwarebased controller for PC-based control, OptoOPCServer[™] software for exchanging data with OPC 2.0-compliant client software applications, and OptoDataLink[™] for exchanging SNAP PAC System data with databases (including Microsoft SQL Server, Microsoft Access, and MySQL), text files, and email systems).



PAC Control Basic is a graphical, flowchart-based programming tool for machine control and process applications. Using PAC Control, you create, download, and run strategies on a SNAP PAC controller. In addition to flowchart programming with subroutine capability, PAC Control includes a powerful, built-in scripting language based on C and other procedural languages.

PAC Control Professional adds the ability to import legacy OptoControl strategies, support for older *mistic*[™] serial I/O



units, and support for the dual independent Ethernet ports on a SNAP PAC controller.

A SNAP R-series controller simultaneously runs up to 16 PAC Control flowcharts, although the PAC Control strategy can actually contain a much larger number of flowcharts. The total number of flowcharts is limited only by the memory available for strategy storage.

PAC Display Basic is an intuitive HMI package for building operator interfaces, or *projects*, for communicating with a SNAP PAC controller. PAC Display offers a full-featured HMI including alarming, trending, and a built-in library of 3,000 industrial automation graphics.

PAC Display Professional adds the ability to import projects created in OptoDisplay, part of the legacy Opto 22 FactoryFloor[®] software suite, and using redundant Ethernet communication links on SNAP PAC controllers. PAC Display Professional can also connect to Ethernet-based FactoryFloor controllers running OptoControl strategies.

SoftPAC is a software-based programmable automation controller (PAC)designed for PC-based control. Programmed just like an Opto 22 hardware PAC, SoftPAC runs your PAC Control strategy independently on an embedded or standalone PC. SoftPAC takes advantage of a PC's speed and file capabilities for applications requiring extended file storage,



Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

frequent access to files, math-intensive processes, or a large number of control flowcharts running at the same time.

OptoOPCServer is a fast, efficient OPC 2.0-compliant server for communicating with many Opto 22 products, including SNAP PAC controllers and I/O units, plus legacy Opto 22 Ethernet-based controllers and I/O. Using OptoOPCServer, you can consolidate data from all these Opto 22 systems into the OPC client software of your choice, such as third-party HMI and data acquisition packages, and custom software applications you create with tools such as Visual C++[®].

OptoDataLink is a software application that makes it easy to share data from the SNAP PAC System with commonly used databases, including Microsoft SQL Server, Microsoft Access, and MySQL, as well as text files. The I/O points and strategy variables already created in your PAC Control strategy are automatically available for OptoDataLink to use for data exchange.

PAC Manager is a utility application for assigning IP addresses to SNAP PAC controllers and brains, reading or changing basic controller configuration, and configuring and testing I/O.

Software Availability

PAC Project Basic is included with SNAP PAC controllers and is a free download from the Opto 22 website.

PAC Project Professional is available for purchase on our website. To get it immediately, you can buy and download the software from the Opto 22 website at www.opto22.com; the CD and printed documentation will be shipped to you. You can also separately purchase PAC Control Professional, PAC Display Professional, SoftPAC, OptoOPCServer, and OptoDataLink as needed.

Specifications

Specifications are continued on the following page.

Processor	200 MHz 32-bit ColdFire $^{\ensuremath{\mathbb{B}}}$ 5475 with integrated floating-point unit (FPU)
Memory Total RAM	Wired+Wireless models 32 MB (10 MB available for PAC Control strategy and 4 MB for file stor- age. Other models 16 MB (5 MB available for PAC Control strategy and 2 MB for file storage)
Battery-backed RAM Flash	2 MB (1 MB available for PAC Control strategy) 8 MB (3.25 MB available for PAC Control strategy; 384 KB available for file storage)
Removable storage	(Models with manufacture dates of November 2008 and newer. Requires firmware R9.4a or higher and loader R6.1a or higher) MicroSD card slot: supports microSD or microSDHC cards to 32 GB. (Note: Models with card slots and firmware R8.4 through R9.3e support microSD cards up to 2 GB only.)
Backup battery	Rechargeable (recharges whenever the brain has power), 3-year power-off data retention ¹
Communication (wired) Ethernet RS-232 serial	Two independent 10/100 Mbps Ethernet network interfaces (RJ-45 connectors) Each interface has a separate IP address. Connects to host and I/O. One RS-232 serial port ² with hardware handshaking. Connects to host (via modem and PPP) or serial device. Cannot connect to serial I/O.
Communication (wireless) ³ Topologies Security Frequency 802.11a Frequency 802.11b/g Transmit Power Antenna Connector Roaming	Wireless LAN interface with separate IP address. Infrastructure, Ad-Hoc 802.11i: AES - Compatible with WPA2 Personal, TKIP - Compatible with WPA Personal, WEP. Note: TKIP/AES security is not supported in Ad-Hoc mode. 5.180–5.240 GHz, 5.745–5.825 GHz 2.412–2.472 GHz, 2.484 GHz 15 dBm maximum Reverse polarity SMA (RP-SMA or RSMA) Supported within an SSID (Service Set Identifier) only
I/O unit compatibility	SNAP PAC I/O units: SNAP PAC R-series and EB-series I/O units

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2007–2016 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

DATA SHEET Form 1594-160505

PAGE

4

Power requirements	5.0–5.2 VDC @ 1.5 A
Hold-down screw	Torque: 8 in-lb (0.9 N-m)
Connector screw	Torque: 1.7 in-lb (0.19 N-m)
Environmental Operating temperature Storage temperature Humidity	-20 °C to 60 °C -40 °C to 85 °C 0% to 95% relative humidity, non-condensing
Software PAC Project Basic PAC Project Professional	Includes programming, HMI software, and configuration software; included with purchase of con- troller. PAC Project Basic plus OPC 2.0-compliant OPC server, database connectivity,OptoControl strat- egy and OptoDisplay project importing, and support for Ethernet link redundancy or network seg- menting.
Number of charts that can run simultaneously	16
Agency approvals and cer- tifications	All models: CE, RoHS, DFARS All models except -FM models: UL (-W models only) U.S., FCC Part 15 Subpart C; Canada, IC RSS-210 (-FM models only) Factory Mutual approved, ATEX
Warranty	30 months from date of manufacture
Other features	 Multiple protocol support including TCP/IP, FTP, EtherNet/IP, Modbus/TCP, SNMP v2.0c, OptoMMP™, and SMTP Built-in I/O processor handles up to 16 digital⁴, analog, and serial I/O modules on the same rack Real-time clock FTP server/client with file system (in RAM and in removable storage) Scratch Pad area for peer-to-peer communication Configurable link redundancy or segmented networking for I/O-controller subnetting (when using PAC Project Professional)

¹ Models manufactured before July 1, 2007 have a user-replaceable 3-volt CR2032 Lithium battery (typical service life with power off: 5 years).

² Connecting to a serial device requires configuration in PAC Manager; PAC Control handles communication.

³ Requires a Wired+Wireless model (SNAP-PAC-R1-W or SNAP-PAC-R2-W).

⁴ SNAP-PAC-R1s with serial numbers lower than 600,000, and all SNAP-PAC-R1-Bs, are limited to eight 4-channel digital modules per rack; remaining eight can be analog, serial, and high-density digital modules.

Form 1594-160505 DATA SHEET

OPTO 22

SNAP PAC R-Series Controllers


Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2007–2016 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

PAGE

System Architecture

For the network shown in this diagram, either PAC Project Professional or PAC Project Basic can be used.

SNAP PAC R-series Controller in Basic Network Configuration



In this diagram, the SNAP PAC R-series controller uses one network interface to communicate with host computers and control I/O. The controller controls I/O on its own rack and on other Ethernet-based I/O units.


SNAP PAC R-Series Controllers **OPTO 22**

o DATA SHEET Form 1594-160505

System Architecture (continued)

The network shown in this diagram requires PAC Control Professional, PAC Display Professional, and OptoDataLink.

SNAP PAC R-series Controller Segmenting Ethernet Networks



This diagram shows two SNAP PAC I/O units connected together over an Ethernet network and controlled by a SNAP PAC R-series controller running a PAC Control strategy.

The controller is also connected to a larger, separate enterprise Ethernet network to provide data to PCs running Opto 22's PAC Display HMI software, OptoOPCServer, and OptoDataLink. Sitting between the two networks, the SNAP PAC R-series controller segments enterprise traffic from the control network.

If you use a Wired+Wireless PAC (SNAP-PAC-R1-W or SNAP-PAC-R2-W), one of these networks can be a wireless LAN. See the following page for an example.


Porm 1594-160505 PAGE

7

System Architecture (continued)

The network shown in this diagram requires a Wired+Wireless R-series controller (SNAP-PAC-R1-W or SNAP-PAC-R2-W).

SNAP PAC R-series Controller Segmenting Wired and Wireless Networks



This diagram shows a SNAP PAC Wired+Wireless controller running a PAC Control strategy and controlling one or more remote I/O units via a wireless access point.

The controller is also connected to a separate, wired enterprise network through one of its wired Ethernet network interfaces. The controller could just as easily talk to the I/O units through a wired network and segment the enterprise PCs on a wireless LAN.

In addition, because the Wired+Wireless PAC has two wired interfaces plus the wireless one, it could segment three networks—for example, a wired control network, a wired enterprise network, and a wireless connection with a laptop for maintenance or testing purposes.

SNAP PAC R-Series Controllers **OPTO 22**

8 DATA SHEET Form 1594-160505


Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

© 2007–2016 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

System Architecture (continued)

The network shown in this diagram requires PAC Control Professional, PAC Display Professional, and OptoDataLink.

SNAP PAC R-series Controller in Redundant Network Configuration




Opto 22 Redundant Network

This diagram shows two SNAP PAC R-Series controllers functioning as I/O unit brains connected to two separate Ethernet networks. This configuration addresses the concern that an Ethernet network may fail or need maintenance, leaving the PC running OptoOPCServer and OptoDataLink, the PC running PAC Display, the controller, and the I/O units unable to communicate.

In this configuration, if one network goes down, devices can still communicate because the SNAP PAC R-series controllers and the SNAP PAC S-series controllers both have two network interfaces, and each PC in this system has two network interface cards.

Using a Wired+Wireless PAC (SNAP-PAC-R1-W or SNAP-PAC-R2-W) makes it possible for one of these networks to be a wireless LAN.



U

٨

Ŋ Ŋ

SNAP PAC R-Series Controllers



SNAP PAC R-Series Comparison Chart

The following table compares SNAP PAC R-series controllers with firmware 9.4 or newer.

FEATURE			SNAP-PAC-R1-FM	SNAP-PAC-R1-W	SNAP-PAC-R2	SNAP-PAC-R2-FM	SNAP-PAC-R2-W	SNAP-PAC-R1-B
Factory Mutual approval			•			•		
UL approval		•	•	•	•	•	•	•
	Input latching		•	•	•	•	•	•
	On/off status		•					
	Watchdog timer			•	•	•	•	
	High-speed counting (up to 20 kHz) ¹			•				•
Digital I/O	Quadrature counting ²	٥	•	•				•
point features	On-pulse and off-pulse measurement ^{1,3}	•	•	•				٠
	Frequency and Period measurement ^{1,3}	•	•	•				٠
	TPO (time-proportional output) ³	•	•	٠	•	٠	٠	٠
	Digital totalizing ^{1,3}	•	•	٠	٠	٠	٠	٠
	Pulse generation (N pulses, continuous square wave, on-pulse, and off-pulse) ³	•	•	•	•	•	•	•
	Thermocouple linearization (32-bit floating point for linearized values)	•	٠	٠	٠	•	•	٠
	Minimum/maximum values	•	•	٠	٠	٠	•	٠
	Offset and gain	•	•	•	•	•	•	٠
	Scaling	•	•	•	•	•	•	٠
Analog I/O	TPO (time-proportional output) ⁴	•	•	•	•	•	•	٠
point features	Output clamping	•	•	•	•	•	•	٠
	Filter weight	•	•	•	•	•	•	٠
	Watchdog timer	•	•	•	•	•	•	٠
	Analog totalizing ³	•	•	•	•	•	•	٠
	Ramping ³	•	•	•	•	•	•	٠
High-density digital (HDD) modules (inputs and outputs)		•	•	٠	٠	٠	•	٠
Serial commur	ication modules	•	•	•	•	•	•	٠
PID logic (max	imum 96 PID loops per controller)	•	•	•	•	•	•	٠
Works with PA	C Project software	•	•	•	•	•	•	٠
Runs PAC Control strategies		•	•	•	•	•	•	٥
Wired Ethernet network (two independent network interfaces)		•	•	•	•	•	•	٠
Security for wired network (IP filtering, port access)		•	•	•	•	•	•	٠
Wireless LAN i	nterface (802.11a, b, or g)			•			•	
Security for wir	reless network (WPA2-AES, WPA-TKIP, WEP)			•			•	

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2007–2016 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

Form 1594-160505 DATA SHEET

PAGE 10

FEATURE	SNAP-PAC-R1	SNAP-PAC-R1-FM	SNAP-PAC-R1-W	SNAP-PAC-R2	SNAP-PAC-R2-FM	SNAP-PAC-R2-W	SNAP-PAC-R1-B
OPC driver support	•	•	•	•	•	•	•
Modbus/TCP (slave)	•	•	•	•	•	•	•
EtherNet/IP for communication with Allen-Bradley RSLogix PLCs	•	•	•	•	•	•	•
OptoMMP memory-mapped protocol	•	•	•	•	•	٠	•
SNMP (network management of I/O & variables)	•	•	•	•	•	٠	•
PPP (dial-up and radio modems)	•	•	•	•	•	٠	•
FTP server and client	•	•	•	•	•	٠	•
Email (SMTP client)	•	•	•	•	•	٠	•
UDP Streaming of I/O data to host		•	•	•	•	٠	•
Serial port (RS-232)		•	•	•	•	٠	•
Scratch Pad area—bits, floats, integers, strings		٠	•				
Digital events, alarm events, serial events	• • • • • •		•				
Event messages	•	•	•	•	•	•	•
Data logging in the controller		•	•	•	•	•	•
I/O point data mirroring and memory map copying		•	•	٠	•	٠	•
Realtime clock (RTC)		•	•	٠	•	٠	•
Mounting rack		SNAP PAC racks					B-series
Number of modules per mounting rack	4, 8, 12, or 16 4, 8, 12		4, 8, 12, 16				
Module types and maximum numbers allowed per I/O unit (with largest rack)	16 digital (any type) 16 analog 8 serial 16 analog 16 analog			8 4-ch digital, 8 serial, 16 analog or HDD			

1 4-channel digital modules only; not available on high-density digital modules

2 Requires a SNAP quadrature input module (SNAP-IDC5Q)

3 Requires PAC Control Professional 8.2 or newer, or PAC Control Basic 9.0 or newer

4 Requires a SNAP analog TPO module (SNAP-AOD-29)

DATA SHEET Form 1594-160505

PAGE

11


Connectors and Indicators

2 2

0 L d O

The following information applies to all SNAP PAC R-series controllers except Wired+Wireless models. See page 13 for -W models.

NOTE: The microSD card slot is included in R-series PACs manufactured in November 2008 and later. PACs manufactured before November 2008 do not have this feature..




RS-232 Port (Port 0)

Pin	Description
1	ТХ
2	RX
3	СОМ
4	RTS
5	CTS
6	СОМ
7	DTR
8	DCD

Status and Activity LEDs

Indicator	Description
ACT	Ethernet network activity
LNK	Link established with Ethernet network
STAT	Startup status, control program opera- tional status, MicroSD card access
232	RS-232 serial activity
PPP	PPP status

RS-232 Serial Cable Wiring*



* Minimum requirements for wiring an RS-232 serial cable to connect to a PC. If you want to connect the controller to a modem, see form #1595, the SNAP PAC R-Series Controllers User's Guide, for all eight pin connections.

SNAP PAC R-Series Controllers DATA SHEET

Form 1594-160505

PAGE


12

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

Connectors and Indicators (continued)

The following information applies to Wired+Wireless models (SNAP-PAC-R1-W and SNAP-PAC-R2-W).

NOTE: The microSD card slot is included in R-series PACs manufactured in November 2008 and later. PACs manufactured before November 2008 do not have this feature.



LEDs*


Indicator	Description
ACT	Ethernet network activity
LNK	Link established with Ethernet network
STAT	Startup status, control program opera- tional status, MicroSD card access
232	RS-232 serial activity
WLAN	Wireless LAN status

* The WLAN LED replaces the PPP LED on -W models. These models can still communicate using PPP even though they do not have the indicator.

RS-232 Port (Port 0)

Pin	Description
1	ТХ
2	RX
3	СОМ
4	RTS
5	CTS
6	СОМ
7	DTR
8	DCD

RS-232 Serial Cable Wiring**




* Minimum requirements for wiring an RS-232 serial cable to connect to a PC. If you want to connect the controller to a modem, see form #1595, the SNAP PAC R-Series Controllers User's Guide, for all eight pin connections.

Dimensions

This diagram applies to all R-series PACs except -W models. See the following page for dimensions on Wired+Wireless R-series PACs.

N R




Form 1594-160505 PAGE

DATA SHEET

14

Dimensions

This diagram applies to Wired+Wireless R-series PACs (SNAP-PAC-R1-W and SNAP-PAC-R2-W).



Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2007–2016 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

15